

# SNORRICAM



## ASSEMBLY

1 Screw the 2 loose washers on the two male screws of one of chest plates.  
Note: both chest plates are identical.

2 Mount two ball heads on the same two screws. Tighten the ball head.

3 Screw on the shortest pole onto the top ball head.

4 Attach the main pole to the bottom ball head.




5 Attach a ball head at the end of the shorter pole.


6 Loosen up the ball head connecting the shorter pole to the chest plate.

7 Connect the 2 poles at the connecting cube and lock the cube's position using its knob.

8 Mount a ball head at the end of the extension pole and mount your camera onto the ball head.



9 Slide the extension pole into the longest pole and lock it into position using the clamp at the end of the longest pole.



## PUTTING THE VEST ON

**WARNING:** Make sure to tighten and lock all the ball heads and thumb screws into position before putting the vest on.

**NOTE:** Both chest plates are identical and can be worn either in the front or in the back indifferently.

- 1 To put the vest on, simply connect the 2 sets of straps on the side of each plate around your torso.
- 2 You also have the option of using the 2 over-the-shoulder straps (see in Picture A), but the shoulder straps can be removed as in picture B.
- 3 Loosen the straps to position the Snorricam in the desired position along the torso. Tighten the straps once in the desired position.



**Picture A:**

Snorricam in the front with both side straps and over-the-shoulder straps



**Picture B:**

Snorricam in the back with side straps and over-the-shoulder straps removed

## ADJUSTING THE POSITON OF THE CAMERA

- 1 Use this ball head to adjust the positon of the camera. Make sure to lock the camera's position before any further adjustments.
- 2 Adjust the distance Torso-Camera but loosening up this clamp and pulling the extension pole. Once set, make sure to tighten the clamp to lock the extension pole into position.
- 3 To adjust the angle between the Snorricam and the torso:
  - Make sure that the ball head and clamp from Step 1 and Step 2 are fully tighten before proceeding.
  - Loosen up the 4 joints circled in the picture below (the 3 ball heads and the knob) .
  - Make sure to hold the rig together while the joints are loose.
  - Grab the connecting cube and slide it along the main pole to adjust the angle.
  - Once in the desired position, lock all 4 joints back in position .

